



Technical Specification

EC-Link Specification

Document No: TS-0007

| REV | DATE | REASON FOR ISSUE | PREPARED BY | CHECKED BY | APPROVED BY |
|-----|------------|---|-------------|------------|-------------|
| 1 | 2016-11-01 | First revision | JL | JTS | JL |
| 2 | 2017-10-16 | Updated during implementation | JL | OTE | JL |
| 3 | 2018-31-07 | Changed behavior of commands when armed/disarmed. | OTE | JL | GAØ |
| 4 | 2020-05-12 | Updated maximum POD bytes | GAØ | MS | GAØ |
| 5 | 2020-10-21 | Added Modbus TCP and VX-100-BU | JL | GAØ | GAØ |
| | | | | | |

This document is proprietary and confidential. No part of this document may be disclosed in any manner to a third party without the prior written consent of Vision Remote AS.

Table of Contents

| | | |
|-------|--|----|
| 1 | Introduction | 4 |
| 1.1 | Purpose..... | 4 |
| 1.2 | System Overview | 4 |
| 1.3 | Definitions and Abbreviations | 4 |
| 1.4 | Workflow..... | 5 |
| 1.5 | References | 5 |
| 1.6 | Revision History | 6 |
| 2 | General..... | 7 |
| 2.1 | Operational Mode | 7 |
| 2.2 | Value encoding | 7 |
| 2.3 | BU configuration | 7 |
| 3 | Profibus DP | 8 |
| 3.1 | Getting started guide | 8 |
| 3.2 | GSD file..... | 8 |
| 3.3 | Profibus DP Master Configuration..... | 9 |
| 3.4 | Setting Profibus address..... | 9 |
| 3.5 | Profibus interface..... | 9 |
| 3.5.1 | Operation Mode LED..... | 9 |
| 3.5.2 | Status LED | 10 |
| 3.5.3 | Profibus Connector | 10 |
| 4 | Profinet RT..... | 11 |
| 4.1 | Getting started guide | 11 |
| 4.2 | GSDML file | 11 |
| 4.3 | Profinet IO controller configuration | 12 |
| 4.4 | Setting station name and IP address | 12 |
| 4.5 | Profinet interface | 12 |
| 4.5.1 | Network Status LED..... | 13 |
| 4.5.2 | Module Status LED | 13 |
| 4.5.3 | Link/Activity LED | 13 |
| 4.5.4 | Profinet Connector..... | 13 |
| 4.5.5 | Media Redundancy | 14 |
| 5 | Modbus TCP..... | 15 |
| 5.1 | Getting started guide | 15 |
| 5.2 | Modbus TCP functionality | 15 |
| 5.3 | Setting IP configuration..... | 16 |
| 5.4 | Modbus TCP interface | 17 |
| 5.4.1 | Network Status LED..... | 17 |
| 5.4.2 | Module Status LED | 17 |
| 5.4.3 | Link/Activity LED | 17 |
| 5.4.4 | Ethernet Connector | 18 |
| 6 | Input data..... | 19 |
| 6.1.1 | BU state..... | 20 |
| 6.1.2 | Link status | 20 |

| | | |
|-------|---------------------------------|----|
| 6.1.3 | RU state | 20 |
| 6.1.4 | RU joystick..... | 21 |
| 6.1.5 | Switch state | 21 |
| 7 | Output data | 22 |
| 8 | Data flow | 23 |
| 8.1 | Command input | 23 |
| 8.2 | Command output..... | 24 |
| 8.3 | Periodic input data | 24 |
| 8.4 | Periodic output data..... | 24 |
| 8.5 | Armed vs. Disarmed..... | 25 |
| 8.6 | G-Link fallback operation | 26 |
| 9 | Troubleshooting guide..... | 26 |

1 Introduction


1.1 Purpose

This document specifies the fieldbus interface used for the VisionRemote EC-Link. This document covers the Profibus DP, Profinet RT and Modbus TCP variants.

This document is valid both for VM-110-BU and VX-100-BU. The term BU is used for both.

Please note that data presented on the RU graphical screen and commands entered on graphical screen are handled by the RU application. The RU application is adapted to suit the actual machine. This document specifies how to exchange this data over EC-Link, but the actual data content must be specified in a machine specific document.

1.2 System Overview




1.3 Definitions and Abbreviations

See system overview in section 1.2.

Machine controller is used for the computer or PLC that communicates with BU using the fieldbus interface specified in this document.


The term 'Input' is used for data sent from BU to machine controller. The term 'Output' is used for data sent from machine controller to BU. These terms are identical to PLC terms for dedicated peripheral units:



Input data is described in chapter 6. Output data is described in chapter 7.

1.4 Workflow

Typical workflow when developing a PLC application and an accompanying RU application is:



1.5 References

SS-0001 Vision Remote VM-110 System Specification

SS-0003 Vision Remote VX-100 System Specification

1.6 Revision History

| Revision | Description |
|-----------------|--|
| 1 | Initial revision. |
| 2 | Updated during implementation: <ul style="list-style-type: none">- Extended specification to cover both Profinet and Profibus.- Changed document name to cover both Profibus and Profinet.- Added description of different operational modes.- Extended values for RU state and Link state. |
| 3 | The behavior of the command messages when Armed and disarmed has been changed. Now commands are forwarded to all remotes regardless of arming state. |
| 4 | Corrected maximum bytes to 51200 in chapter 7.4 |
| 5 | Added chapter 5 describing Modbus TCP interface. Specified that document covers both VM-110-BU and VX-100-BU. Renamed document accordingly. |

2 General

2.1 Operational Mode

The fieldbus interface in BU can be configured for one of the following operational modes:

| Mode | Description |
|------------------|--|
| Input Only | Inputs (status, joysticks, and switches) are transferred on fieldbus |
| Input + Commands | Inputs and commands from/to GUI application are transferred on fieldbus |
| Standard | Inputs, commands, and periodic data to GUI application transferred on fieldbus |

The operational mode of your system is configurable, see section 2.3.

2.2 Value encoding

All multi bytes values are encoded in big-endian format (most significant byte first).

All data specified in this document uses one of the following encodings:

- Unsigned integer with a length of 8, 16 or 32 bits.
- Signed integer with a length of 8, 16- or 32-bits using two's complement.

All size values in this document are to be interpreted as bytes.

2.3 BU configuration

The BU is configured and managed using the built-in web server. Connect your computer to the BU network port labelled "TEST PORT" and open the web page at 192.168.32.1. The user interface will be specified in a separate document.

3 Profibus DP

3.1 Getting started guide

Depending on your system configuration, you can skip some of the steps in this guide:

| Mode | Skip steps |
|------------------|-------------|
| Input Only | 4,5,7 and 8 |
| Input + Commands | 5 and 8 |
| Standard | None |

To successfully integrate the BU in your Profibus system, do the following:

1. Add the BU to your Profibus master configuration. See section 3.3.
2. Configure Profibus address on BU. See section 2.3.
3. Connect BU to your Profibus network. See section 3.5.3.

At this stage, the Profibus is running, and data from BU is available in the machine controller. If your system is not of type "Input only", the BU will still indicate an error because it will not detect that the machine controller acknowledges and sends data to/from BU.

4. Add Software in machine controller to update CAO (Command Acknowledge Output), see section 8.1.
5. Add software in machine controller to update PCO (Periodic Counter Output), see section 8.4.

At this stage the BU will indicate normal operation.

6. Add software in machine controller to handle periodic data from RU.
7. Add software in machine controller to send commands to RU application and to handle commands from RU application.
8. Add software in machine controller to send periodic process data to RU application.
9. Enjoy.

3.2 GSD file

BU is delivered with a GSD file to be used when configuring the Profibus master.

3.3 Profibus DP Master Configuration

To add BU to your Profibus master, import the supplied GSD file into your Profibus master configuration tool. Use the configuration tool to add a node of type "VM-110-BU-DP".

Then add a single module depending on the operational mode of the BU:

| Mode | Module to select | Input bytes | Output Bytes |
|------------------|---------------------------|-------------|--------------|
| Input Only | VM-110-BU Input Only | 64 | 0 |
| Input + Commands | VM-110-BU Input + Command | 64 | 20 |
| Standard | VM-110-BU Standard | 64 | 224 |

3.4 Setting Profibus address

The Profibus address can be configured in two different ways:


- With an address in range 1 to 125 set as part of BU configuration. See section 2.3. This is the recommended solution.
- By using the "Set slave address" Profibus function. This function is enabled by selecting address 126 in BU configuration.

When using the "Set slave address" function, the BU configuration utility can be used to reset EC link configuration to factory default. This will reset the slave address to 126.

3.5 Profibus interface

The Profibus interface module is a Anybus CompactCom M40 module made by HMS Industrial Networks, part number AB6600.

| Nr | Item |
|----|--|
| 1 | Operation Mode LED |
| 2 | Status LED |
| 3 | Profibus Connector, 9-pin female D-Sub |



3.5.1 Operation Mode LED

| State | Indication |
|----------------|------------------------------|
| Off | Not online / No power |
| Green | Online, data exchange |
| Flashing Green | Online, clear |
| Red, 1 Flash | Parametrization error |
| Red, 2 Flashes | Profibus Configuration error |

3.5.2 Status LED

| State | Indication |
|----------------|--|
| Off | Not initialized |
| Green | Initialized |
| Flashing Green | Initialized, diagnostic event(s) present |
| Red | Exception error |

3.5.3 Profibus Connector

9-Pin D-Sub Female

| Pin | Signal | Description |
|---------|--------------|-------------------------------|
| 1 | - | - |
| 2 | - | - |
| 3 | B-Line | Positive RxD/TxD, RS485 level |
| 4 | RTS | Request to send |
| 5 | GND Bus | Ground (isolated) |
| 6 | +5V Output | +5V termination power |
| 7 | - | - |
| 8 | A Line | Negative RxD/TxD, RS485 level |
| 9 | - | - |
| Housing | Cable Shield | Connected to protective earth |

This layout is according to the industry standard for Profibus.

4 Profinet RT

4.1 Getting started guide

Depending on your system configuration, you can skip some of the steps in this guide:

| Mode | Skip steps |
|------------------|-------------|
| Input Only | 4,5,7 and 8 |
| Input + Commands | 5 and 8 |
| Standard | None |

To successfully integrate the BU in your Profinet system, do the following:

1. Add the BU to your Profinet controller configuration. See section 4.3.
2. Configure Profinet IP address and station name on BU. See section 2.3.
3. Connect BU to your Profinet network. See section 4.5.4.

At this stage, the Profinet is running, and data from BU is available in the machine controller. If your system is not of type "Input only", the BU will still indicate an error because it will not detect that the machine controller acknowledges and sends data to/from BU.

4. Add Software in machine controller to update CAO (Command Acknowledge Output), see section 8.1.
5. Add software in machine controller to update PCO (Periodic Counter Output), see section 8.4.

At this stage, the BU will indicate normal operation.

6. Add software in machine controller to handle periodic data from RU.
7. Add software in machine controller to send commands to RU application and to handle commands from RU application.
8. Add software in machine controller to send periodic process data to RU application.
9. Enjoy.

4.2 GSDML file

BU is delivered with a GSDML file to be used when configuring the Profinet controller.

4.3 Profinet IO controller configuration

To add BU to your Profinet controller, import the supplied GSDML file into your Profinet controller configuration tool. Use the configuration tool to add a node of type "VM-110-BU-PIR".

Then add modules depending on the operational mode of the BU:

| Mode | Module in slot 1 | Module in slot 2 | Input bytes | Output Bytes |
|------------------|------------------|------------------|-------------|--------------|
| Input Only | Inputs | <none> | 64 | 0 |
| Input + Commands | Inputs | Command Outputs | 64 | 20 |
| Standard | Inputs | Standard Outputs | 64 | 224 |

Set the station name configured into the BU in the controller configuration.

4.4 Setting station name and IP address


Use the Profinet controller configuration tool to program a unique station name into BU. If your system has multiple base units, each BU must have a unique station name.

There is normally no need to configure an IP address in BU. The Profinet controller assigns the IP address during startup using Profinet DCP.

4.5 Profinet interface

The Profinet interface module is a Anybus CompactCom M40 module made by HMS Industrial Networks, part number AB6605.

| Nr | Item |
|----|----------------------------|
| 1 | Network Status LED |
| 2 | Module Status LED |
| 3 | Link/Activity LED (port 1) |
| 4 | Link/Activity LED (port 2) |



4.5.1 Network Status LED

| State | Indication |
|-----------------|--|
| Off | No power / No Connection with IO Controller |
| Green | Connection with IO controller established. IO controller in RUN state. |
| Green, 1 Flash | Connection with IO controller established. IO controller in STOP state or IO data bad. IRT synchronization not finished. |
| Green, Blinking | Used by engineering tools to identify the node on the network. |
| Red | Major internal error in module. |
| Red, 1 Flash | Station name is not set. |
| Red, 2 Flashes | IP address is not set. |
| Red, 3 Flashes | Configuration error. Expected Identification differs from Real Identification. |

4.5.2 Module Status LED

| State | Indication |
|-----------------------|---|
| Off | Module not initialized by application. |
| Green | Normal Operation. |
| Green, 1 Flash | Diagnostics event(s) present in module. |
| Red | Exception error/ Fatal event. Major internal error in module. |
| Green/Red alternating | Firmware update in progress. Do NOT power off the module |

4.5.3 Link/Activity LED

| State | Indication |
|-------------------|---|
| Off | No Link established (not connected) |
| Green | Link established, no communication |
| Green, flickering | Link established, communication present |

4.5.4 Profinet Connector

2 RJ45 connectors. The Ethernet interface operates at 100 Mbit, full duplex, as required by PROFINET.

| Pin | Description |
|---------|--|
| 1,2,4,5 | Connected to chassis ground over serial RC circuit |
| 3 | RD- |
| 6 | RD+ |
| 7 | TD- |
| 8 | TD+ |
| Housing | Cable shield |

The shield of the RJ45 connector is not connected directly to Protective Earth in BU. For further information, see PROFINET Installation Guideline for Cabling and Assembly, available for download at www.profinet.com.

4.5.5 Media Redundancy

The Profinet interface module has 2 RJ45 network connectors and support the Media Redundancy Protocol (MRP) as a Media Redundancy Client (MRC).

5 Modbus TCP

5.1 Getting started guide

Depending on your system configuration, you can skip some of the steps in this guide:

| Mode | Skip steps |
|------------------|---------------|
| Input Only | 4,5,6,8 and 9 |
| Input + Commands | 6 and 9 |
| Standard | None |

To successfully integrate the BU in your system, do the following:

1. Set IP configuration of BU Modbus TCP interface. See section 5.3.
2. Connect BU to your network. See section 5.4.4.
3. Add Software in machine controller to periodically read input data from BU. See section 5.2.
4. Add Software in machine controller to periodically write output data to BU. See section 5.2.
5. Add Software in machine controller to update CAO (Command Acknowledge Output), see section 8.1.
6. Add software in machine controller to update PCO (Periodic Counter Output), see section 8.4.
At this stage, the BU will indicate normal operation.
7. Add software in machine controller to handle periodic data from RU.
8. Add software in machine controller to send commands to RU application and to handle commands from RU application.
9. Add software in machine controller to send periodic process data to RU application.
10. Enjoy.

5.2 Modbus TCP functionality

The Modbus TCP standard is available at <https://www.modbus.org/specs.php>. BU is a Modbus TCP server (slave) supporting up to 4 simultaneous connections.

BU supports all Modbus data types, and they access the BU input and output data like this:


| Modbus data type | Input data mapping | Output data mapping |
|------------------|--------------------|--|
| Coils | | Bitwise mapping: Bit 0 is LSbit of first byte (byte 0) Bit 1791 is MSbit of last byte (byte 223) |

| | | |
|-------------------|--|--|
| Discrete Inputs | Bitwise mapping: Bit 0 is LSbit of first byte (byte 0) Bit 511 is MSbit of last byte (byte 63) | |
| Holding Registers | 16-bit register mapping: Register 2048 is byte 0 and 1. Register 2079 is byte 62 and 63. | 16-bit register mapping: Register 0 is byte 0 and 1. Register 111 is byte 222 and 223. |
| Input Registers | 16-bit register mapping: Register 0 is byte 0 and 1. Register 31 is byte 62 and 63. | |

Registers are transferred with first byte in the lower 8 bits.

5.3 Setting IP configuration


BU Modbus TCP interface must be configured with a valid IP configuration. The recommended method is to use a tool named HMS IPconfig. This tool can be downloaded free of charge from the HMS website: <http://anybus.com>



5.4 Modbus TCP interface

The Modbus TCP interface module is a Anybus CompactCom M40 module made by HMS Industrial Networks, part number AB6603.

| Nr | Item |
|----|----------------------------|
| 1 | Network Status LED |
| 2 | Module Status LED |
| 3 | Link/Activity LED (port 1) |
| 4 | Link/Activity LED (port 2) |



5.4.1 Network Status LED

| State | Indication |
|-----------------|--|
| Off | No IP address or in state EXCEPTION. |
| Green | At least one Modbus message received. |
| Green, flashing | Waiting for first Modbus message. |
| Red | IP address conflict detected, FATAL ERROR. |

5.4.2 Module Status LED

| State | Indication |
|-----------------------|---|
| Off | Module not initialized by application. |
| Green | Normal Operation. |
| Red | Exception error/ Fatal event. Major internal error in module. |
| Red, flashing | Minor fault |
| Green/Red alternating | Firmware update in progress. Do NOT power off the module |

5.4.3 Link/Activity LED

| State | Indication |
|--------------------|---|
| Off | No Link established (not connected) |
| Green | Link established, 100 Mbit, no communication |
| Green, flickering | Link established, 100 Mbit, communication present |
| Yellow | Link established, 10 Mbit, no communication |
| Yellow, flickering | Link established, 10 Mbit, communication present |

5.4.4 Ethernet Connector

2 RJ45 connectors. The Ethernet interfaces supports 100 Mbit or 10 Mbit, full or half duplex.

| Pin | Description |
|------------|--|
| 1,2,4,5 | Connected to chassis ground over serial RC circuit |
| 3 | RD- |
| 6 | RD+ |
| 7 | TD- |
| 8 | TD+ |
| Housing | Cable shield |

The shield of the RJ45 connector is AC coupled to PE connector on BU.

6 Input data

Input data means data sent from BU to machine controller. The layout is like this:

| Field | Offset [Bytes] | Size [Bytes] | Description |
|--------------------|----------------|--------------|---|
| PCI | 0 | 1 | Periodic Counter Input. Incremented by BU each time new data is available. See section 8.3. |
| CCI | 1 | 1 | Command Counter Input. Incremented by BU when a new command has been received from the armed RU application. See section 8.1. |
| PAI | 2 | 1 | Periodic Acknowledge Input. Used to acknowledge that periodic data has been processed by BU. See section 8.4. |
| CAI | 3 | 1 | Command Acknowledge Input. Used to acknowledge that a command to RU application has been processed by BU. See section 8.2. |
| Command from RU | 4 | 16 | Command received from RU application. |
| BU state | 20 | 1 | State of BU. See section 6.1.1. |
| VLAPs | 21 | 1 | Number of VLAPs connected to BU. In range 0..3. |
| Unarmed RUs | 22 | 1 | Number of unarmed RUs communicating with this BU. |
| EG-Link status | 23 | 1 | State of EG-Link. See section 6.1.2. |
| EC-Link status | 24 | 1 | State of EC-Link. See section 6.1.2. |
| C-Link status | 25 | 1 | State of C-Link. See section 6.1.2. |
| Armed RU | 26 | 2 | Unique ID of RU that is currently armed. Set to 0 if no remote is currently armed. When 0, all the following fields are set to 0. |
| RU state | 28 | 1 | State of RU. See section 6.1.3. |
| RU battery | 29 | 1 | RU battery level in range 0..100 (%). |
| RU C-Link RSSI | 30 | 1 | RSSI level of C-Link in range 0..100 (%). |
| RU cable | 31 | 1 | Set to 0 if operating on wireless VisionLink. Set to 1 if operating on cable. |
| RU docked | 32 | 1 | Set to 1 when RU is in docking station. Otherwise 0. |
| RU disabled | 33 | 1 | Set to 0 if remote is enabled. Set to 1 if disabled due to tilting. Set to 2 if disabled due to inactivity. Set to 3 if disabled by other causes. |
| RU joystick 1 to 4 | 34 | 4 * 2 | Position of joystick 1 to 4. See section 6.1.4. |
| RU switch 1 to 8 | 42 | 8 * 2 | State of switch 1 to 8. See section 6.1.5. |
| RU encoder value | 58 | 1 | Encoder value. Is incremented and decremented as encoder is rotated. Wraps around freely, so machine controller must handle this if needed. |
| RU encoder switch | 59 | 1 | Set to 1 when encoder is pushed down. 0 if not. |
| Spare | 60 | 4 | Spare bytes for future use. Set to 0 for now. |

6.1.1 BU state

The following BU state values are defined:

| Value | Interpretation |
|-------|---|
| 0x00 | Initial. BU is not fully operative yet. |
| 0x01 | Stopped. BU is armed against a specific RU, and RU signals that BU should stop. |
| 0x02 | External link error. Monitoring has detected an error in EC-Link or EG-Link. |
| 0x03 | Blocked. Communication is lost with an armed RU. Turn on RU and rearm to resume operation. |
| 0x04 | Failed. Self-diagnostics has discovered a fatal internal error in BU. |
| 0x10 | Disarmed. BU is not armed against a specific RU. Check 'Unarmed RUs' to see if any unarmed RUs are connected. |
| 0x11 | Armed. BU is armed against a specific RU. |

The ES-Link relays will be open when BU state is less than 0x10.

6.1.2 Link status

The following link state values are defined:

| Value | Interpretation |
|-------|--|
| 0 | Unused. The link is not used in this system. |
| 1 | Operational. The link operates normally. |
| 2 | No Link. Link is not operational because no valid data has been received. |
| 3 | Link error. Configuration error in system causes link to be inoperative. |
| 4 | Interface Error. Error reported by link interface module. |
| 5 | Data error. Link is up, but there is an error in the exchanged data. |
| 6 | Passive. Link is not in use. Can only be reported on C-Link when no remote is armed. |

6.1.3 RU state

The following RU state values are defined:

| Value | Interpretation |
|-------|--|
| 0 | Initial. No RU is armed yet. |
| 1 | Disarmed. Only used internally. |
| 2 | Armed. Remote is armed, but movements are disabled due to tilting or inactivity. |
| 3 | Enabled. Remote is armed and enabled. Movements are allowed. |
| 4 | Stopped. Armed remote has stopped causing ES-Link relay to open. |

RU enters stopped state if one of the following happens while the RU is armed:

- Stop switch is activated
- Free fall or shock sensor is triggered
- A fatal error has occurred in RU


6.1.4 RU joystick

Joystick position as a signed integer in range +/- 1000. A passive joystick is reported as 0.

Single axis joysticks are oriented like this:



Dual axis joysticks are oriented like this:



6.1.5 Switch state

Note that the protocol and the electronics are prepared for up to 8 switch positions. The RU has room for 4 switches if it is equipped with a stop switch, and 5 if not. The switches are numbered from left to right.

The value reported in switch state varies with the fitted switch:

| Equipment | Value reported |
|--------------------------|---|
| Pushbutton | 1 if button is pushed. 0 if not. |
| 2-position toggle switch | 1 if switch is in upper/right position. 0 if not. |
| 3-position toggle switch | 0 in center position. 1 in upper/right position. -1 in lower/left position. |
| Potentiometer | 0 in counterclockwise position, up to 1000 in clockwise most position. |
| Pushbutton with LED | 0 means not pushed. 1 means pushed. Add 2 if LED is lit. |
| Dual color LED | 0 means OFF. 1 means GREEN. 2 means RED. 3 means AMBER. |

When fitted with LEDs, the LEDs are controlled by the RU application. If the machine controller shall control these LEDs, functionality must be implemented in RU application to forward this data to the LEDs.

7 Output data

Output data means data sent from machine controller to BU. The layout is like this:


| Field | Offset | Size | Description |
|---------------------|--------|------|---|
| PCO | 0 | 1 | Periodic Counter Output. Shall be incremented by machine controller each time new data is available. See section 8.4. |
| CCO | 1 | 1 | Command Counter Output. Shall be incremented by machine controller when a new command shall be sent to the armed RU. See section 8.2. |
| PAO | 2 | 1 | Periodic Acknowledge Output. Not used yet. |
| CAO | 3 | 1 | Command acknowledge Output. Used to acknowledge that a command from RU has been processed. See section 8.1. |
| Command to RU | 4 | 16 | Command to be sent to RU application. |
| Periodic data size | 20 | 2 | Number of bytes of process data to be transferred to RU application |
| Periodic data block | 22 | 1 | Data block number of this process data. Starting from 0. |
| Spare | 23 | 1 | Spare byte for future use. Set to 0 for now. |
| Periodic data | 24 | 200 | Periodic data to be sent to RU application. |

8 Data flow

8.1 Command input

When the operator executes a command on GUI (e.g. presses a "start" button or alters a set-point), a command is sent from RU application to machine controller. BU increments CCI to tell that a new command is available.

The machine controller should implement command handling logic like this:




BU monitors CAO and indicates an error if a command has not been acknowledged for 2000ms. If this error occurs when an RU is armed, the ES-Link relays will open, and the machine is forced to a safe state.

Note that it is up to the RU application and the machine controller to decide on the data content in the 16 bytes that forms a command.

8.2 Command output

When machine controller needs to send a command to RU application, it should implement logic like this:



It is up to the machine controller and RU application to decide on the data content in the 16 bytes that forms a command. If your application does not need to send any commands, then just leave CCO at the default value.

8.3 Periodic input data

BU updates the input data every 125ms, and then increments PCI. The machine controller shall monitor PCI and bring the system to a safe state if PCI stops incrementing. A suitable timeout is 500ms.


8.4 Periodic output data

Periodic output data typically contains machine state values and measurement parameters. It is up to the RU application and the machine controller to agree on the interpretation of this data.

The machine controller shall update the periodic data to RU and increment PCO periodically.

BU monitors PCO and indicates an error if this value has not been incremented for 2000 ms. If this error occurs when an RU is armed, the ES-Link relays will open.

The machine controller shall write the size of the periodic data to be transferred to RU application. If this number is higher than 200, the machine controller must multiplex the data like this:



EC-Link handles up to 51200 bytes of periodic output data. (200 bytes * 256 blocks)

8.5 Armed vs. Disarmed

The BU handles multiple connected RUs simultaneously, but only one of them can be armed.

| Data | When remote is armed | When remote is disarmed |
|-----------------|--|---|
| Periodic Input | Data from remote is sent. | No data from remote is sent, but number of remotes is reported. |
| Periodic Output | Data from machine controller is sent to RU application. | Data from machine controller is sent to RU application. |
| Command Input | Commands from RU application are sent to machine controller. | Commands from RU application are sent to machine controller. |
| Command Output | Commands from machine controller are sent to RU application. | Commands from machine controller is sent to RU application. |

8.6 G-Link fallback operation

Wireless G-Link is based on WiFi, so a limited operational range and occasional dropouts must be expected. When G-Link fails, the system will use C-Link instead. C-Link is more reliable but has limited capacity. When operating on C-Link, data will be prioritized like this:

| Priority | Data | Description |
|----------|-----------------|--|
| 1 | Periodic Input | This data is important for machine control and system safety. |
| 2 | Command Input | Operator commands are more important than display updates. |
| 3 | Command Output | Critical alarms can be sent to RU application as commands to ensure priority over Periodic Output. |
| 4 | Periodic Output | Periodic update of graphical display data has lowest priority. |

As seen by the operator, the system will be operative with a failing G-Link, but the response time on screen commands will be longer, and the periodic update of screen information will be slower.

When a RU is armed, fallback operation is limited to this RU. If no remote is armed, fallback will work on a single disarmed RU only.

9 Troubleshooting guide

Any errors in the EC-Link causes BU to be locked in initial state, and normal operation is not possible. The LCD display on BU shows the EC link error state like this:

| Message | Troubleshooting |
|------------------|---|
| EC: No Data | No data exchanged on fieldbus. Check machine controller configuration and connection between BU and machine controller. |
| EC: Cfg. Error | Configuration mismatch between machine controller and BU. |
| EC: Module Error | Error in fieldbus interface module. |
| EC: Bad data | Fieldbus is configured correctly, and data exchange is operative. The machine controller fails to increment PCO periodically or to acknowledge commands from RU application using CAO, see chapter 7. |